COMMERCIAL REFRIGERATOR AND FREEZER
OWNER'S MANUAL

Glass Door Merchandisers

Models: G368BMF, D368BMF, D768BM2F, G1.2YBM2F

This manual contains important information about your *Admiral Craft* unit. Please read the manual thoroughly prior to equipment set-up, operation and maintenance.
Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty.
MUST READ!!!

INSTALLATION

- This refrigeration system will operate best when it is installed in an area that has cool, dry air.
- Do not put in direct sunlight.
- Be sure that the unit is properly grounded. All units are equipped with a three-prong ground plug on the service cord for your safety.
- Make sure that there is at least 6 inches of clearance on both sides and the back of the cabinet.
- This refrigeration system should be located away from heat and moisture-generating equipment such as ovens, etc
- Unit should be installed on a surface that can support the weight of the entire unit including its contents. Surface should also be flat.
- This unit was designed for indoor use only. Outdoor use will void any warranty.

PRECAUTIONS

- Use caution to not overload the outlet
- Do not use flammable products near the unit or spray the unit with water
- If you must unplug the unit, you must wait at least 6 minutes before plugging it back in. If you do not wait the 6 minutes, the compressor may fail.
- When cleaning:
  - Be sure to unplug the power cord with dry hands prior to cleaning
  - Cracking or discoloration of plastic parts may occur if you use harsh abrasive solvents or polishing agents. Avoid such products.
- If you will not be using the unit for an extended period of time, unplug the unit, wipe the inside with a dry cloth. Door may be left slightly open to eliminate moisture and odor

OPERATION AND MAINTENANCE

- When loading the unit:
  - Do not block the air ducts (located at the back and top of the unit) with product as this will block the air flow thereby decreasing the unit's performance. For best results, keep at least 6 inches of clearance between the product and the air duct.
- The temperature controller is located at the right, front corner of the ceiling. The default setting is "4".
- Do not leave the unit door open for extended periods of time when the unit is on and plugged in. For best results, close the door immediately after use.

TROUBLESHOOTING

SYMPTOMS	POSSIBLE SOLUTION
COMPRESSORS WILL NOT START	Ensure that the power cord is plugged in to appropriate outlet Check circuit for blown fuse
INADEQUATE PERFORMANCE	Make sure that the door is closed Move the unit away from anything that generates heat Check if there is a blockage in the air duct Make sure that the unit is in a well ventilated area with a minimum clearance of 6” from any walls Check to see if refrigerant is low Make sure that the temperature controller is set correctly Clean the condenser if necessary
NO INTERIOR LIGHT	Ensure that the bulb is properly installed in the socket Check to see if the bulb needs to be replaced Turn off the light switch, then turn it on again
UNIT IS NOISY	Check for any loose parts or mounting Make sure the unit is on a flat sturdy surface Make sure all tubing is away from any contact that would cause a rattling sound Make sure there is minimum clearance of 6” from any walls
THERE IS CONDENSATION ON CABINET AND/OR FLOOR	Make sure that the gasket on door or head is creating a proper seal. Reduce the humidity in the area

NOTES:

RETAIN THIS MANUAL FOR FUTURE REFERENCE

Please read the entire manual carefully before installing and operating. If certain recommended procedures are not followed, warranty claims will be denied.

Notice: Admiral Craft reserves the right to make changes in design and specifications without prior notice.

MODEL #: _____

SERIAL #: _____

COMPRESSOR SERIAL #: _____

PURCHASE DATE: _____